GMUND



Gmund Classic

_

PRINTING TIPS

Printing – Offset printing

- Letterpress

Silk-screen printingBlind embossingHot foil stampingPaper etching

Die cutting

Recommendations for offset printing

- Screens up to 80 I/cm

Proof printing on same paper stock

Under colour reduction when applying strong ink coverage

Low absorption of ink, therefore:

- Use of fully oxidative drying inks

- Print dusting, low printing stacks

- Careful drying, a minimum of 24 hours

 Increase pressure and use soft rubber blankets to achieve optimal covering in the dents of the paper surface when applying area printing

Special advice

Not suitable for laser and inkjet printers

Acid free, pH-neutral

- The paper surface can vary slightly from making to making

 Natural papers have a top side and a bottom side. It is recommended, to use the top side as the front side for the print project.

 For printing and processing, the recommendations of the manufacturers of machines, inks, glues, lamination and embossing foils etc. have to be followed. For any damages caused by improper application, Gmund cannot accept liability.

 Engraving is an ancient craft. The use of modern textures or metallised papers is a challenge. Tests are recommended prior to starting the print run.

Further information

world-en.gmund.com