



Gmund Hanf

—

PRINTING INFORMATION

- | | |
|--|--|
| Printing | <ul style="list-style-type: none"> - Offset printing - Letterpress - Silkscreen - Blind embossing - Hot-foil embossing - Stamping |
| Recommendations for offset printing | <ul style="list-style-type: none"> - Raster widths up to 80 l/cm. - Adjust the lithograph depending on the paper's color. - Proof printing on same paper stock. - Under color removal (UCR) with ample ink. - Deposits of hemp dust or inclusions on the offset blanket are avoidable and require regular cleansing of the rubber blankets. - 600 g/m² can be offset printed only by cardboard printing machines (thickness of the material = ca. 1 mm). <p>Low absorption of the printing ink, therefore:</p> <ul style="list-style-type: none"> - Print using only oxidative-drying inks - For uncoated paper use soft rubber blankets (55° shore-hardness or lower) - Print dusting, low printing stack - Dry thoroughly for a minimum of 24 hours |
| Recommendations for laser / inkjet printing | <ul style="list-style-type: none"> - 120 g/m² is suitable for laser and inkjet printers in office environments. - Suitability for laser and inkjet printers refers to unprinted sheets in the delivered format. - Further processing (offset printing, cutting, embossing, etc.) can adversely affect the paper and its suitability for printing with laser and inkjet printers. - If subsequent laser printing is to be done on printed sheets that were pre-produced with offset printing, then the offset printing should be done with laser-compatible inks and a low application of moistening agents. An offset raster surface with maximally 40% coverage is recommended. - Tests on the respective equipment are strongly recommended. |
| Special features | <ul style="list-style-type: none"> - Inclusions, the look of the sheet and the color may vary slightly from one fabrication to the next due to the composition of the materials and the utilization of natural plant-based raw materials. - The printing technique should be adapted to suit the unusual surface of the paper. - Acid-free, pH-neutral. - Natural papers have an upper side and an underside. It is recommended to use the paper's upper surface as the front of the printed item. - When printing and processing, follow the manufacturer's recommendations for machines, printing inks, adhesives, laminating foils, stamping foils, etc. Gmund accepts no liability for damage resulting from incorrect use. |
| Additional information | <ul style="list-style-type: none"> - world-en.gmund.com |